



**Fitting Instructions: SUB018**

|                         |  |
|-------------------------|--|
| <b>Vehicle:</b>         | Subaru XV SUV Wagon  |
| <b>Towing Capacity:</b> | 1200kg   |
| <b>Fitting Kit:</b>     | <ul style="list-style-type: none"> <li>4x 1½ x 3/8 bolts on wire (grind edges), flat &amp; star washers, nuts</li> <li>2x 5½ x 3/8 bolts, flat &amp; star washers, nuts</li> <li>2x 100mm crush tubes</li> <li>2x 10mm hole plates</li> <li>1x D shackle</li> <li>2x Towbar Rating Labels</li> </ul> |

|    |  |
|----|--|
| 1. | Remove interior floor trim to expose chassis rails. Remove the black plastic cover on the centre hole both sides which aligns with the fore most chassis hole under car.   |
| 2. | Bumper cut required prior to fitment of towbar. Locate centre of bumper, cut 45mm each side of centre & 60mm up from edge of bumper.   |
| 3. | Undercar feed 1½ x 3/8 bolts on wire (2 each side) into the fore most holes in the chassis (refer step 1). Ensure wires are bent flat against underside of chassis.  |
| 4. | Mount towbar to underside of chassis, aligning rear most holes in towbar with bolts fitted in previous step. Fit flat / star washers & nuts. Do not tighten at this stage.   |
| 5. | Ensure that wires are clear of the front most hole in the towbar. Feed 5½ x 3/8 bolts via hole plates / crush tubes & chassis holes (refer step 1) inside of car, via towbar. Fit star / flat washers & nuts undercar. |
| 6. | Centralise towbar on bumper cut & tighten all bolts.   |
| 7. | Replace floor trim removed in step 1.  |
| 8. | Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.   |