



**Fitting Instructions: SUB021**

- Vehicle:** Subaru Impeza Sedan (12/2016 - ON)  
Subaru Forester (07/2018 ON)
- Towing Capacity:** 1200kg
- Fitting Kit:**
- 2x 1¼ x ¾ bolts, nuts & spring / flat washers
  - 2x Hole plates ( 3 x 3 )
  - 1x 'D' shackles
  - 2x Towbar Rating Labels

1.	Remove tail lights.
2.	Remove bumper.
3.	Remove and discard crash support panel retaining bolts & nuts.
4.	Mount towbar to back panel using bolts & nuts removed in previous step. Do not tighten at this stage.
5.	Ensure towbar is central on car, tighten bolts & nuts on back panel.
6.	In boot area remove rubber grommets that align with holes in towbar undercar. Feed 3/8 bolts via hole plates in boot area, undercar fit flat / spring washers & nuts. Tighten bolts.
7.	<p>Bumper cut required prior to refitting bumper.</p> <p><b>IMPREZA</b> - Locate center of bumper &amp; cut 40mm each side of centre and 65mm up from bottom edge of bumper.(bumper cut not visible).</p> <p><b>FORESTER</b> – Locate centre of bumper &amp; cut 40mm each side of centre and 90mm up from edge of bumper. (bumper cut no visible).</p>
8.	Refit items removed in steps 1 – 2.
9.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.