

# BTA Towbars

Australia's Towing Equipment Specialist



## Fitting Instructions: SUB07H

<b>Vehicle:</b>	Subaru outback 01/2021 - on
<b>Towing Capacity:</b>	2000kg/200kg
<b>Fitting Kit:</b>	2x 1 1/2 x 3/8 bolts, nuts & star / flat washers
	2x Hole plates (75 x 75mm) 10mm hole ( round edges)
	2x 'D' shackles
	2x Towbar Rating Labels

1.	Remove tail lights.
2.	Remove rear bumper bar and spare tyre. Remove and discard 2 rubber grommets in spare wheel well floor.
3.	Remove sensor from crash support (Passenger side). remove & discard crash support panel retaining bolts & nuts.
4.	Mount towbar to back panel using bolts & nuts removed in previous step. Do not tighten at this stage.
5.	Fit two bolts with 75 x 75mm plates in spare wheel well through towbar undercar brace, fit flat, star washers and nuts.
6.	Tighten all bolts.
7.	Bumper cut required prior to refitting bumper. Locate center of bumper & cut 40mm each side of center and 170mm up from bottom edge of bumper.
8.	Refit items removed in steps 1 – 2. Refit crash support sensor to rear panel.
9.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.