

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**SUZ11 FITTING INSTRUCTIONS
SIERRA WAGON WITH COILS.**

REMOVE TWO 10mm BOLTS FROM TANK AREA WHICH WILL CORRESPOND WITH TOWBAR CENTRE SUPPORTS.
MOUNT TOWBAR TO REAR CHASSIS USING 12mm BOLTS SUPPLIED.
FIT 10mm BOLTS SUPPLIED TO CENTRE SUPPORTS.
TIGHTEN ALL BOLTS.

FITTING KIT

4 – 12 x 30mm FINE BOLTS, SPRING & FLAT WASHERS.
2 – 12mm TAPPED PLATES ON WIRE.
2 – 12mm NUTS.
2 – 10 x 35mm FINE BOLTS, SPRING & FLAT WASHERS.
1 – DEE SHACKLE.