

Fitting Instructions



SKU

PRODUCT

T4D147

TAG Heavy Duty Towbar to suit Holden Rodeo (1981 - 02/2003)



Scan for latest version of these instructions

SPECIFICATIONS

- Towbar Class: Heavy Duty
- Towing Capacity: 1800kg

IN THIS GUIDE

- Fitment Instructions
- Torque Settings
- Warranty Info

Towbar Fitting Instructions



Step-By-Step Instructions

Warning:

Safety First: Always use correct safety equipment.

This towbar is NOT to be drilled, cut, welded or modified in any way.

Check the surrounding area before drilling into chassis or body panels for fuel lines, wiring harnesses and other components that may be a hazard.

General:

Before fitting this towbar read fitting instructions and check installation hardware is correct.

Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.

After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.

If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change.

If you are not sure then ask your towbar supplier.

Tighten all bolts as specified on the last page.

1. REMOVE ALL BOLTS AND BRACKETS FROM TOWBAR TAKING NOTE OF LOCATIONS.
 - 1.1. INSTALL LONG BRACKETS INTO CHASSIS AND SECURE FORWARD WELDED NUT WITH 3/8 BOLT, PLATE AND WASHER THROUGH EXISTING HOLE IN UNDERSIDE OF CHASSIS.
 - 1.2. REMOVE SHIPPING HOOK FROM VEHICLE IF FITTED.[RETAIN]
2. FIT TOWBAR SECURING WITH 1/2 INCH BOLTS, NUTS AND WASHERS THROUGH SIDES OF TOWBAR.
 - 2.1. PLACE ANGLE BRACKETS TO UNDERSIDE OF CHASSIS AND SECURE USING M10 BOLTS, NUTS AND WASHERS THROUGH TOP AND SIDES OF ANGLE.
 - 2.2. IF SHIPPING HOOK WAS REMOVED THEN M10 X 1.25 PITCH BOLTS TO BE INSTALLED DRIVERS SIDE.
 - 2.3. FIT SHIPPING HOOK ONTO SIDE OF TOWBAR WITH ORIGINAL BOLTS AND NUTS PROVIDED.

Towbar Fitting Instructions



3. TIGHTEN ALL BOLTS TO SPECIFIED RATINGS.
 - 3.1. FIT BALL MOUNT WITH PIN AND CLIP PROVIDED.
 - 3.2. ATTACH RATINGS STICKER TO DRIVERS SIDE DOOR PILLAR

Torque table for bolt tightening

| Metric GRADE 8.8 | UNC GRADE 8 |
|-------------------------|--------------------|
| M6 – 12.5 Nm | 3/8 – 50 Nm |
| M8 – 30 Nm | 1/2 – 125 Nm |
| M10 – 60 Nm | 5/8 – 245 Nm |
| M12 – 103 Nm | |
| M14 – 167 Nm | |
| M16 – 270 Nm | |

TAG Warranty Statement

SWD warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us direct by phone on 1300 669122 or visit www.swd.com.au