

**BORONIA TOWBARS P/L**  
**1/12 EDINA RD**  
**FERNTREE GULLY**  
**VIC 3156**  
**PH: (03) 9752 2642**  
**FAX: (03) 9752 2575**

**TOY84A / TOY2H / TOY84B FITTING INSTRUCTIONS**

**TOYOTA FOUR RUNNER 1989**

**TOWING CAPACITY 1250KG**

FIT TOWBAR UP TO REAR OF CHASSIS. HOLD FIRM WITH JACK.  
FEED WIRE TO BOLTS SUPPLIED INTO CHASSIS PICKING UP EXISTING  
HOLES & THROUGH TOWBAR.  
ONCE ALL ARE FITTED - TIGHTEN.  
FIT (16mm) BOLTS SUPPLIED THROUGH TIE DOWN HOOKS & INTO TOWBAR  
& TIGHTEN.  
CHECK ALL BOLTS FOR TIGHTNESS.

**FITTING KIT:**

2 - 1.1/2" x 1/2" WIRE TO BOLTS, NUTS & SPRING WASHERS.  
2 - 1.1/2" x 1/2" BOLTS, NUTS & SPRING WASHERS.  
6 - 1/2" FLAT WASHERS.  
2 - 16mm x 45mm BOLTS, SPRING & SQUARE FLAT WASHERS.  
1 - D SHACKLE.