

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**TOY33 CAMRY/AURION SEDAN 07/06 ON
FITTING INSTRUCTIONS:**

REMOVE PLASTIC UNDERCAR PANEL.

REMOVE REAR BUMPER BAR, HELD BY 6 SCREWS AND 2 CENTRE PLUGS, (2 SCREWS, ONE EITHER SIDE - ARE HIDDEN ABOVE REAR WHEEL ARCH).

REMOVE REAR IMPACT BEAM AND DISCARD.

REMOVE SPARE WHEEL THEN REMOVE 2 RUBBER GROMMITS LOCATED IN FLOOR OF SPARE WHEEL WELL.

MOUNT TOWBAR TO REAR PANEL USING ORIGINAL NUTS, C/W STAR AND FLAT WASHERS SUPPLIED – TIGHTEN.

FIT BOLTS SUPPLIED WITH PLATES TO EXISTING TWO HOLES IN WHEEL WELL FLOOR, FIT NUTS WITH SPRING AND FLAT WASHERS – TIGHTEN.

DRILL REMAINING HOLE (10MM) VIA TOWBAR UNDER VEHICLE, FIT BOLT WITH PLATE THEN NUT, WITH SPRING AND FLAT WASHER – TIGHTEN.

REFIT REAR BUMPER BAR.

REFIT PLASTIC UNDERCAR PANEL, CUTTING CENTRE SECTION TO FIT AROUND TOWLUG BACKING PLATE SECTION.

AURION INNER BUMPER REQUIRES 75 x 20mm SECTION CUT OUT AT TOWBAR CENTRE SUPPORT AREA JUST ABOVE TOWLUG BACKING PLATE SO BUMPER CAN BE REFITTED. (THIS CUT CANNOT BE SEEN)

NOTE :- *ELECTRONIC CONTROL MODULE MUST BE FITTED TO THIS VEHICLE. ON MODELS BUILT AFTER APRIL 2007 ECM IS INSTALLED IN BOOT. ON MODELS PRIOR TO APRIL 2007 ECM WIRING IS TO BE FITTED UNDER PASSENGER SIDE DASH.*

FITTING KIT:

3 – 11/2 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS.

6 – 10mm STAR WASHERS AND FLAT WASHERS.

3 – 11mm HOLE PLATES.

1 – DEE SHACKLE.