

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

TOY44 FITTING INSTRUCTIONS
TOYOTA SPACIA TOWNACE YR2206
TOWING CAPACITY 1000KG

REMOVE REAR BUMPER BAR

PLACE TOWBAR INTO POSITION, FIT 16mm BOLT, SPRING WASHER & PLATE SUPPLIED, VIA TIE DOWN HOOK- DRIVERS SIDE.

FIT TAPPED PLATE INTO PASSENGER SIDE SUB FRAME, ALIGN WITH EXISTING HOLE IN SUBFRAME, FIT 12mm BOLT, SPRING & FLAT WASHER SUPPLIED VIA TOWBAR SIDE ARM TO TAPPED PLATE.

REMOVE TOWBAR TONGUE.

REFIT BUMPER BAR.

FIT 12mm BOLT SUPPLIED VIA TOWBAR & INTO EXISTING TAPPED HOLE IN SUB FRAME - TIGHTEN.

TIGHTEN 16mm BOLT & 10mm BOLT.

REFIT TOWBAR TONGUE.

CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

1 - 12mm x 40mm BOLT, SPRING & FLAT WASHER.

1 - 10mm x 35mm BOLT, SPRING & FLAT WASHER.

1 - 10mm TAPPED PLATE.

1 - 16mm x 45mm BOLT, SPRING WASHER & PLATE (ON TOWBAR) .

1 - D SHACKLE.