

**BORONIA TOWBARS  
1/12 EDINA RD  
FERNTREE GULLY  
VIC 3156  
(03) 9752 2968**

**FITTING INSTRUCTIONS  
TOY38 COROLLA HATCH 2003–2007  
TOY39 COROLLA SEDAN & WAGON 2003-2007  
TOY47 COROLLA SEDAN 2007-ON**

REMOVE SPARE WHEEL.

REMOVE RUBBER GROMMET FROM FLOOR OF SPARE WHEEL WELL.

REMOVE REAR TIE DOWNS.

MOUNT TOWBAR TO EXISTING HOLES IN REAR SUBFRAME USING 12mm BOLTS COMPLETE WITH SPRING & FLAT WASHERS SUPPLIED, TIGHTEN. FIT REMAINING BOLT COMPLETE WITH PLATE VIA HOLE IN SPARE WHEEL WELL, FIT SPRING & FLAT WASHER THEN NUT – TIGHTEN. CHECK ALL BOLTS FOR TIGHTNESS.

**FITTING KIT:**

- 4 – 12 x 30mm BOLTS, SPRING & FLAT WASHERS
- 1 – 11/4 x 3/8 BOLT, NUT SPRING & FLAT WASHER
- 1 – LARGE 10mm HOLE PLATE
- 1 – DEE SHACKLE