

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

TOY48 FITTING INSTRUCTIONS
YARIS 4 DOOR SEDAN
TOWING CAPACITY 700KG

REMOVE SPARE WHEEL.
REMOVE REAR TAIL LIGHTS.
REMOVE REAR BUMPER BAR.
REMOVE & DISCARD REAR CRASH SUPPORT PANEL.

NOTE: ON SOME MODELS 10MM MAY NEED TO BE CUT FROM THE BASE OF THE CENTRE SUPPORT TO PREVENT IT FROM FOULING ON THE TOWBAR BACKING PLATE.

FIT TOWBAR USING ORIGINAL BOLTS TO EXISTING HOLES IN REAR PANEL, TIGHTEN.
DRILL 3/8 HOLE THROUGH TOWBAR BACKING PLATE (IF TWO HOLES PRESENT - USE HOLE NEAREST TO TOWBALL MOUNT).
INSERT SPACER BLOCK BETWEEN BACKING PLATE & TYRE WELL.
FIT 2-1/2 x 3/8 BOLT WITH PLATE SUPPLIED THROUGH BASE, SPACER BLOCK, TOWBAR, FIT NUT COMPLETE WITH SPRING WASHER – TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.
REFIT BUMPER BAR, TAIL LIGHTS & SPARE WHEEL.

FITTING KIT:

1 – 2 1/2 x 3/8 BOLT, NUT, SPRING & FLAT WASHER
1 – SPACER BLOCK (5 x 3/8 HOLE PLATES)
1 – 3/8 HOLE PLATES
1 – DEE SHACKLE