

BTA Towbars

Australia's Towing Equipment Specialist



Fitting Instructions: TOY04H

Vehicle: Toyota Landcruiser 60 Series Wagon (11/1980 – 01/1985)

Towing Capacity: 2000kg

Fitting Kit:

- 6x 2 x ½" bolts, nuts & star washers
- 6x Plates
- 2x 'D' shackles
- 2x Towbar Rating Labels

1.	Remove rear tie down hook.
2.	Mount tow hitch to rear sub frame using 6 - ½" bolts supplied (via original holes in sub-frame) complete with plates, star washers & nuts, do not tighten at this stage.
3.	Tighten remaining nuts.
4.	Apply Towbar Rating Labels to driver's side door sill <u>and</u> non-removable part of the towbar.