

**BORONIA TOWBARS
1/12 EDINA ROAD
FERNTREE GULLY
VIC 3156
(03)9752 2642**

**TOY6H FITTING INSTRUCTIONS
SWB 40 SERIES LANDCRUISER**

REMOVE BUMPERETTE HOLDING BOLTS (2) FROM EACH BUMPERETTE WHICH ALIGN WITH TOWHITCH SIDE ARMS.
MOUNT TOWHITCH USING 12mm BOLTS SUPPLIED COMPLETE WITH SPRING & FLAT WASHERS, DO NOT TIGHTEN AT THIS STAGE.
FIT 8mm BOLTS WITH SPRING & FLAT WASHERS VIA TOWHITCH SIDE ARMS.
TIGHTEN 12mm & 8 mm BOLTS.
DRILL REMAINING TWO HOLES VIA TOWHITCH CENTRE SUPPORTS, FIT BOLTS WITH PLATES SUPPLIED – TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

4 – 12 x 30mm FINE THREAD BOLTS, SPRING & FLAT WASHERS.
2 – 8 x 35mm BOLTS, SPRING & FLAT WASHERS.
2 – 11/2 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS.
2 – DEE SHACKLES.