

**BORONIA TOWBARS P/L**  
**1/12 EDINA RD**  
**FERNTREE GULLY**  
**VIC 3156**  
**PH: (03) 9752 2642**  
**FAX: (03) 9752 2575**

**TOY78 FITTING INSTRUCTIONS**  
**TOYOTA TARAGO VAN 07/1990 - ON**  
**TOWING CAPACITY 1200KG**

REMOVE TIE DOWN HOOKS WHICH ALIGN WITH TOWBAR HOLES.  
FIT TOWBAR UP TO VEHICLE USING (12mm) BOLTS SUPPLIED.  
FIT TAPPED PLATES TO HOLES ALIGNED WITH TOWBAR.  
FIT (1/2") BOLTS SUPPLIED - TIGHTEN.  
CHECK ALL BOLTS FOR TIGHTNESS.

**FITTING KIT:**

6 - 12mm x 40mm FINE BOLTS, FLAT & SPRING WASHERS.  
1 - D SHACKLE.