

**BORONIA TOWBARS  
1/12 EDINA RD  
FERNTREE GULLY  
VIC 3156  
(03) 9752 2968**

**TOY 52/7H FITTING INSTRUCTIONS  
RAV4 WAGON 1994 - 2000  
TOWING CAPACITY 1200KG**

REMOVE REAR TIE DOWN HOOKS.  
MOUNT TOWBAR TO TIE DOWN HOOK HOLES USING (12mm)  
BOLTS SUPPLIED - TIGHTEN.  
DRILL (10mm) HOLES VIA TOWBAR INTO REAR PANEL.  
FIT WIRE TO BOLTS, FLAT & SPRING WASHERS - TIGHTEN.

**NOTE:**

REAR DOOR FAILS ON TOWBALL. TOWBALL MUST BE REMOVED  
TO ALLOW DOOR TO OPEN FULLY.

**FITTING KIT:**

4 – 12mm x 40mm FINE BOLTS, SPRING & FLAT WASHERS  
2 – 1 ¼ x 3/8 WIRE TO BOLTS, NUTS, SPRING & FLAT WASHERS  
2 – DEE SHACKLES