

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

TOY81 FITTING INSTRUCTIONS
TOYOTA COROLLA LIFTBACK / SECA 1985 - 88
TOWING CAPACITY 700KG

REMOVE TWO BUMPER BAR HOLDING BOLTS, DRIVERS SIDE AT EXHAUST AREA.

FIT TOWBAR UP TO VEHICLE USING (10mm) BOLTS SUPPLIED FIT VIA TOWBAR & INTO EXISTING HOLES (DRIVERS SIDE).

FIT WIRE TO BOLTS SUPPLIED IN THROUGH OPEN END OF CHASSIS PASSENGER SIDE & THROUGH EXISTING HOLES IN BASE OF CHASSIS - VIA TOWBAR.

TIGHTEN ALL BOLTS.

REMOVE SPARE WHEEL.

DRILL (10mm) HOLES VIA TOWBAR TAIL SECTION INTO SPARE WHEEL AREA, FIT PLATES & BOLTS SUPPLIED - TIGHTEN.

RECHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

2 - 10mm x 35mm FINE BOLTS, SPRING & FLAT WASHERS.

2 - 1.1/2" x 3/8" BOLTS, NUTS & SPRING WASHERS.

2 - 3" x 1.1/2" x 3/8" HOLE PLATES.

1 - D SHACKLE.