BORONIA TOWBARS P/L 1/12 EDINA RD FERNTREE GULLY VIC 3156 PH: (03) 9752 2642 FAX: (03) 9752 2575

## <u>TOY81A FITTING INSTRUCTIONS</u> <u>TOYOTA COROLLA HATCH AE80 / 82</u> <u>TOWING CAPACITY 700KG</u>

FIT TAPPED PLATE SUPPLIED WITH TOWBAR, INTO PASSENGER SIDE CHASSIS & ALIGN WITH EXISTING HOLES IN CHASSIS. FIT TOWBAR UP TO VEHICLE & MOUNT VIA TIE DOWN HOOK ON DRIVERS SIDE. FIT (10mm) BOLT SUPPLIED VIA TOWBAR & THROUGH CHASSIS INTO PLATE - TIGHTEN. REMOVE SPARE WHEEL, DRILL (10mm) HOLE VIA TOWBAR TAIL SECTION

REMOVE SPARE WHEEL, DRILL (10mm) HOLE VIA TOWBAR TAIL SECTION INTO BOOT AREA.

FIT BOLT & PLATE THROUGH.

THEN FIT SPRING WASHER & NUT - TIGHTEN.

TIGHTEN ALL BOLTS.

## FITTING KIT:

1 - 3" x 1/2" x 3/8" HOLE PLATE.

1 - 1.1/2" x 3/8" BOLT, NUT & SPRING WASHER.

1 - D SHACKLE.