

BORONIA TOWBARS P/L
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
PH: (03) 9752 2642
FAX: (03) 9752 2575

TOY90 FITTING INSTRUCTIONS
TOYOTA CRESSIDA MX83 1988 - ON
TOWING CAPACITY 1000KG

REMOVE BUMPER BAR.
FIT TOWBAR TO DRIVERS SIDE TOWING HOOK & TIGHTEN.
HOLD TOWBAR FIRM WITH JACK & DRILL (TWO) HOLES (10mm) VIA
TOWBAR ON PASSENGER SIDE.
FIT BOLTS SUPPLIED & TIGHTEN.
DRILL (10mm) HOLE VIA SMALL ARM ON TOWBAR UP TO BOOT FLOOR.
FIT BOLT, PLATE & TIGHTEN.
DRILL (10mm) HOLE VIA TOWBAR THROUGH CROSSMEMBER TOWARD
FRONT OF CAR & FIT BOLT ETC. & TIGHTEN.
CHECK ALL BOLTS FOR TIGHTNESS.

FITTING KIT:

2 - 1.1/2" x 3/8" BOLTS, NUTS, SPRING & FLAT WASHERS.
2 - 1.1/4" x 3/8" BOLTS, NUTS, SPRING & FLAT WASHERS.
1 - 3" x 3" x 3/8" HOLE PLATE.
1 - D SHACKLE.