

**BORONIA TOWBARS
1/12 EDINA ROAD
FERNTREE GULLY
VIC 3156
(03) 9752 2642**

**TOY93 FITTING INSTRUCTIONS
COROLLA AE92 HATCH 1989 / 1994
TOWING CAPACITY 800KG**

REMOVE REAR BUMPER BAR & SPARE WHEEL.
REMOVE BUMPER BAR BRACKETS FROM BUMPER.
REMOVE BOLTS FROM BRACKETS DRILL (10mm) HOLES & FIT NEW
BOLTS SUPPLIED.
FIT TOWBAR UP TO VEHICLE MAKING SURE TOWBAR
CORRESPONDS WITH EXISTING HOLES.
DRILL (10mm) HOLE EITHER SIDE VIA TOWBAR & FIT BOLTS
SUPPLIED - TIGHTEN.
REFIT BUMPER - TIGHTEN.
DRILL (10mm) HOLES VIA TOWBAR INTO SPARE WHEEL WELL.
FIT BOLTS & PLATES SUPPLIED - TIGHTEN.
REFIT SPARE WHEEL.

FITTING KIT:

2 – 1 ¼ x 3/8 BOLTS, NUTS & SPRING WASHERS
6 – 1 ½ x 3/8 BOLTS, NUTS & SPRING WASHERS
6 – 3/8 FLAT WASHERS
2 – 3 x 1 ½ x 3/8 HOLE PLATES
1 – DEE SHACKLE