



Towbar Fitting Instructions  
To Suit TOYOTA TARAGO 7/90-ON  
Part Number TT107A  
Rating 1000Kg

1. Ensure all hardware items have been included.
2. Remove shipping hooks.
2. Slide exhaust hanger rubbers off their pins on muffler, to allow exhaust to drop.
4. While pulling muffler down, slide towbar into position, lining up with shipping hook bolt holes.
5. Using four bolts supplied, bolt on and tighten.
6. Tighten all bolts to torque listing below.

**RECOMMENDED ASSEMBLY TORQUE LISTING**

<b><u>Diameter</u></b>	<b><u>Grade 8.8 Bolt</u></b>
	<b>Nm</b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

# TRAILBOSS

Towbar Fitting Instructions  
To Suit TOYOTA TARAGO 7/90-ON  
Part Number TT107A  
Rating 1000Kg

