

TRAILBOSS

Towbar Fitting Instructions To Suit TOYOTA STARLET 5/96-ON Part Number TT121 Rating 600Kg

1. Ensure all hardware items have been included.
2. Remove rear shipping hooks.
3. While holding muffler down, fit towbar up over muffler to align with tapped shipping hook holes.
4. Fit 1.25 pitch bolts supplied complete with shipping hooks. (**NOTE:** Passenger's side hook reverser)
5. Using angle support bracket as guide, drill two 11mm holes through spare wheel well. Fit bolts, loose plates, etc. as per sketch.
6. Tighten all bolts to torque listing below.

RECOMMENDED ASSEMBLY TORQUE LISTING

| <u>Diameter</u> | <u>Grade 8.8 Bolt</u> |
|------------------------|------------------------------|
| | Nm |
| M6 | 9.5 |
| M8 | 21.7 |
| M10 | 43.4 |
| M12 | 77.3 |
| M14 | 121.0 |
| M16 | 189.8 |

