



Towbar Fitting Instructions
To Suit TOYOTA COROLLA LIFTBACK 8/98 to 11/01
& 4 DOOR SEDAN 11/99 to 11/01
Part Number TT122
Rating 900Kg

1. Ensure all hardware items have been included.
2. Remove shipping hooks and discard.
3. Remove two plastic screw buttons on bottom edge of bumper bar connecting bumper tabs to vehicle.
4. Lift towbar up and at same time bend back gently bumper tabs so towbar fits between bumper bar and vehicle.
5. Align shipping hook captive nuts with side plate holes and fit the M12 bolts.
6. Tighten all bolts to torque listing below.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

TRAILBOSS

Towbar Fitting Instructions
To Suit TOYOTA COROLLA LIFTBACK 8/98 to 11/01
& 4 DOOR SEDAN 11/99 to 11/01
Part Number TT122
Rating 900Kg

