



Towbar Fitting Instructions
To Suit TOYOTA AVALON SEDAN 6/2000-ON
Part Number TT125A
Rating 1300Kg

1. Ensure all hardware items have been included.
2. Remove and discard both left and right hand shipping hooks.
3. Remove spare wheel.
4. Cut two outer bottom bumper mounting tags as per diagram.
5. From under vehicle, using hole in forward spare wheel support frame as guide, drill into spare wheel well a 11mm hole.
6. Fit spacer tube supplied in between wheel well and support frame to align with hole drilled in step 5.
7. Lift towbar up into position by feeding driver's side up over exhaust pipe.
8. Align holes in towbar angles with shipping hook bolt holes.
9. Fit four M10x35 1.25 pitch bolts, flat washers and spring washers.
10. From inside wheel well fit 32x32 loose plate and coach bolt to tail assemble. Fit spring washer and nut.
11. Tighten all bolts to torque listing below.
12. Refit spare wheel.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

Towbar Fitting Instructions
To Suit TOYOTA AVALON SEDAN 6/2000-ON
Part Number TT125A
Rating 1300Kg

