



Towbar Fitting Instructions
To Suit TOYOTA TARAGO 7/2000-ON
Part Number TT129
Rating 1000Kg

1. Ensure all hardware items have been included.
2. Remove and discard vehicle shipping hooks and bolts
3. Lift towbar up into position and fit 2- M12 x 35 – 1.25p bolts and spring washers through drivers side plate and into captive nuts of vehicle chassis. (loosely)
4. On passengers side, fit M12 x 35 – 1.25p bolt and spring washer through most forward hole in side plate and into captive nut of vehicle chassis. (loosely)
5. On passengers side fit loose bracket using M12 x 35 – 1.25p bolt, spring washer and flat washer as per drawing.
6. On drivers side, fit M12 x 35 – 1.25p bolt, spring washer and loose plate to towbar mounting plate and into captive nut of vehicle chassis.
7. Tighten all bolts to torque listing below.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8

Towbar Fitting Instructions
To Suit TOYOTA TARAGO 7/2000-ON
Part Number TT129
Rating 1000Kg

