

FORD FAIRLANE BA – BF SEDAN 07/03 – 12/07
FORD FALCON AU – BF SEDAN 09/98 – 04/08
FORD FALCON AU – BF WAGON 07/00 – 04/08
FORD TERRITORY SY – SZ WAGON 06/04 – 04/16

PART NO.

UNT201

UNT201FC

FAIRLANE / FALCON SEDAN

1. Fold back the Drivers side rear trim.
2. The Towbar Wiring Harness 8 way connector will be taped to a lead on the floor directly below the R/H/S tail light
3. Connect the wiring harness to the Towbar Wiring Harness 8 way connector.
4. Locate the grommet on the Drivers side, near the 8 way connector and pierce a hole in the middle to allow the towbar wiring harness to be fed through the grommet and out the rear of vehicle.
5. Pull the wiring harness through the grommet to meet the required length.
6. Using cable ties secure the wiring harness to meet the required length.
7. Fit the required socket to the wiring harness and mount the plug to the desired position.
8. Replace Drivers side trim.
9. Test towbar wiring with a trailer testing box.

TERRITORY

1. Remove rear bumper bar
2. Remove rear air vent located on the Drivers side rear panel low down.
3. In the late model vehicles the Towbar Wiring Harness 8 way connector will be sitting in here.
4. If not further inside the vent at the back you will see a hole about 50mm in diameter. The 8 way connector is up in behind this hole, it is lightly taped to another cable. Using 2 fingers feel for this connector and pull down and through the hole.
5. Connect the wiring harness to the Towbar Wiring Harness 8 way connector.
6. Locate the grommet on the bottom of the vent cavity and pierce a hole in the middle to allow the Towbar Wiring Harness to be fed through the grommet and out under the vehicle.
7. Pull the wiring harness through the grommet to meet the required length.
8. Using cable ties secure the wiring harness to meet the required length.
9. Fit the required socket to the wiring harness and mount the plug to the desired position.
10. Replace air vent
11. Refit rear bumper bar.
12. Test towbar wiring with a trailer testing box.

FORD FAIRLANE BA – BF SEDAN 07/03 – 12/07
FORD FALCON AU – BF SEDAN 09/98 – 04/08
FORD FALCON AU – BF WAGON 07/00 – 04/08
FORD TERRITORY SY – SZ WAGON 06/04 – 04/16

PART NO.

UNT201

FALCON WAGON

1. In the rear cargo area locate the access panel for the jack on the Drivers side rear trim.
2. In this cavity you will find a cluster of wiring connectors wrapped in sticky foam.
3. Carefully and slowly peel back this foam until you reveal the Towbar Wiring Harness 8 way Connector.
4. Connect the wiring harness to the Towbar Wiring Harness 8 way connector.
5. Reseal the foam back around the cluster of connectors as neatly as possible.
6. Also in this cavity on the bottom you will see a grommet. (you may need to remove the jack) Pierce a hole in the middle to allow the Towbar Wiring Harness to be fed through the grommet and out under the vehicle.
7. From the underside of the vehicle, pull the wiring harness through the grommet to meet the required length.
8. Be careful of the muffler as it is directly below the exit grommet. Ensure that enough space is allowed between the wiring cable and the muffler when it is fixed in to position.
9. Using cable ties secure the wiring harness to meet the required length.
10. Fit the required socket to the wiring harness and mount the plug to the desired position.
11. Replace Drivers side access trim.
12. Test towbar wiring with a trailer testing box.

