

TOYOTA KLUGER MCU28R WAGON 10/03 – 7/07

PART NO.

UNT245

1. Remove floor panels and trays from the luggage area.
2. Remove the passenger side storage tray.
3. Remove the rear centre trim.
4. Remove rear bumper cover.
5. Locate the rear most grommet on the passenger side and pierce a hole in the middle to allow the towbar wiring harness to be fed through the grommet and out under the vehicle.
6. On the driver side locate and disconnect the vehicle wiring harness from the tail lamp connector.
7. On the towbar wiring harness find the cable marked R/H/S and connect the connectors to the corresponding connectors.
8. Ensure that the wiring harness cable will be hidden behind the trim panels when you replace them.
9. Repeat steps 6, 7 & 8 for the L/H/S.
10. Ensure that the cable running across the back of the vehicle will be hidden when you replace the rear centre trim.
11. Returning to the underside of the vehicle, pull the wiring harness through the grommet to meet the required length.
12. Using cable ties secure the wiring harness to meet the required length.
13. Fit the required socket to the wiring harness and mount the plug to the desired position.
14. Refit centre rear trim.
15. Refit the passenger side storage tray.
16. Refit the floor panels and trays into the luggage area.
17. Test towbar wiring with a trailer testing box.

