

Towbar Wiring Harness Fitting Instructions

TOYOTA HILUX ALL MODELS 04/05 – 07/08

PART NO. UNT249

CAB CHASSIS:

- 1. Unplug the 6 way connector behind the RHS tail light.
- 2. Find the plugs on the harness marked RHS and connect into plugs on car from step 1.
- 3. Follow the same process for the LHS with the remaining two grey plugs.
- 4. Using cable ties secure the wiring harness to meet the required length.
- 5. Fit the required socket to the wiring harness and mount the plug to desired position.
- 6. Test towbar wiring with a trailer testing box.

UTE:

- 1. Remove RHS tail lights.
 - Lower rear tailgate
 - Undo x2 10mm head bolts from side of light
 - Carefully remove light
- 2. Unplug the 6 way connector behind the RHS tail light.
- 3. Find the plugs on the harness marked RHS and connect into plugs on car from step 2.
- 4. Follow the same process for the LHS with the remaining two grey plugs.
- 5. Using cable ties secure the wiring harness to meet the required length.
- 6. Refit both taillights following step 1 in reverse.
- 7. Fit the required socket to the wiring harness and mount the plug to desired position.
- 8. Test towbar wiring with a trailer testing box.

