

FORD COURIER PC-PH UTE & CAB CHASSIS 06/85 - 11/06  
FORD RANGER PJ-PK UTE & CAB CHASSIS 12/06 - 08/11  
MAZDA B SERIES UTE & CAB CHASSIS 06/85 - 11/06  
MAZDA B SERIES UTE & CAB CHASSIS 12/06 - 08/11

PART NO.

**UNT264**

1. On the drivers side underneath the vehicle at the rear you will find a 6 way connection point leading to the rear tail lights.
2. Disconnect the 6 way tail light harness connectors at the rear.
3. On the wiring harness you will find a label marked R/H/S. Connect the 6 way wiring harness connectors to the corresponding connectors.
4. Route the remainder of the wiring harness across the to the passenger side. Using cable ties secure the wiring harness to the vehicle or an existing cable.
5. Repeat steps 1,2 & 3 for the L/H/S.
6. Fit the required socket to the wiring harness and mount the plug to the desired position
7. Connect your towbar wiring test board and test functions

