

**FORD FALCON FG
SEDAN 06/08 – ON**

PART NO.

UNT274**UNT274FC**

1. Fold back the Drivers side rear trim.
2. The Towbar Wiring Harness 6 way connectors will be directly below the R/H/S tail light
3. Disconnect the wiring harness.
4. Connect the Towbar Wiring Harness 6 way connectors to the corresponding vehicle harness.
5. Locate the grommet on the Drivers side, near the 6 way connector and pierce a hole in the middle to allow the towbar wiring harness to be fed through the grommet and out the rear of vehicle.
6. Pull the wiring harness through the grommet to meet the required length.
7. Using cable ties secure the wiring harness to meet the required length.
8. Fit the required socket to the wiring harness and mount the plug to the desired position.
9. Replace Drivers side trim.
10. Test towbar wiring with a trailer testing box.

