

TOYOTA LANDCRUISER 200 SERIES WAGON 09/07 - 12/08

PART NO.

UNT283

1. Remove the rear centre trim.
2. Behind the passenger side rear trim you will locate a single 10 way connector.
3. Connect the Trailer Wiring 10 way connector.
4. Above the 10 way connector, just inside the top trim you will see a 2 way connector pull this connector out gently.
5. Connect the 2 way connector from the Trailer Wiring Harness.
6. Secure the ECU module to side of the internal body panel by peeling off the tape and pressing it firmly into position.
7. Feed the remaining wiring harness down the inside of the trim panel and push out underneath the trim.
8. Pull the wiring harness as far down as you can and allow it to lay in the spare wheel well.
9. In the spare wheel well, or next to the spare wheel, locate a grommet.
10. Pierce the grommet in the centre to allow the wiring harness to be fed through the grommet and out under the vehicle.
11. Returning to the underside of the vehicle, pull the Towbar Wiring Harness through the grommet to meet the required length.
12. Using cable ties secure the Towbar Wiring Harness to meet the required length.
13. Fit the required socket to the wiring harness and mount the plug to the desired position.
14. Replace the side trim panel.
15. Replace the rear centre trim.
16. Test towbar wiring with a trailer testing box.

