

HOLDEN COLORADO RC UTE & CAB CHASSIS 03/08 – 05/12  
ISUZU DMAX RC & TF UTE & CAB CHASSIS 03/08 – ON  
ISUZU MU-X UC WAGON 12/13 - ON

PART NO.
----------

<b>UNT285</b>
---------------

1. Locate the 8 way Towbar wiring connector at the LHS of the rear cross member of the vehicle.
2. Connect the Towbar wiring harness to this connector.
3. Secure the relays to the vehicle, either by cable tying to existing cables or screw to the vehicle.
4. Fit the required socket to the wiring harness and mount the plug to the desired position.
5. Using cable ties, secure the cable along desired route and the required length.
6. Test towbar wiring with a trailer testing box.

