

**BORONIA TOWBARS
1/12 EDINA RD
FERNTREE GULLY
VIC 3156
(03) 9752 2968**

**VOLK1H FITTING INSTRUCTIONS
1996 – TRANSPORTER**

FITTING INSTRUCTIONS:

REMOVE 2 BUMPER BAR HOLDING BOLTS ON PASSENGER SIDE.
MOUNT TOWHITCH ANGLE BRACKET USING BOLTS SUPPLIED
COMPLETE WITH SPRING & FLAT WASHERS, TIGHTEN.

FIT TOWHITCH TO ANGLE BRACKET USING 3/8 BOLTS SUPPLIED
COMPLETE WITH SPRING & FLAT WASHERS, DO NOT TIGHTEN AT THIS
STAGE.

FIT 16mm BOLT WITH LARGE PLATE SUPPLIED TO DRIVERS SIDE TIE
DOWN HOOK.

TIGHTEN 3/8 BOLTS ON PASSENGER SIDE BRACKET.

TIGHTEN 16mm BOLT ON DRIVERS SIDE.

DRILL (10mm) REMAINING 2 HOLES VIA TOWHITCH (ONE EITHER SIDE
REAR SUB FRAME, FIT BOLTS SUPPLIED COMPLETE WITH SPRING &
FLAT WASHERS, TIGHTEN.

CHECK ALL BOLTS FOR TIGHTENESS.

FITTING KIT:

- 1 – 16 x45mm BOLT,NUT, SPRING & FLAT WASHER.
- 1 – 3 x 3 x 1/2 WITH 16mm CLEARANCE HOLE PLATE.
- 1 – 11/2 x 3/8 BOLT, NUT SPRING & FLAT WASHER.
- 4 – 11/4 x 3/8 BOLTS, NUTS, SPRING & FLAT WASHERS.
- 2 – DEE SHACKLES.