

INSTALLATION INSTRUCTIONS

RL1692 - TO SUIT SUZUKI JIMNY 99-ON

PLEASE READ INSTRUCTIONS THROUGH BEFORE YOU BEGIN

WARNING: 1. Do not drill, cut weld or otherwise modify the towbar.

2. If you are using electric welding on a motor vehicle, ~~always~~ check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could ~~destroy~~ any onboard computers. If in doubt, check with the vehicle's manufacturer.

Max. Tow Weight: 1100kg

NOTE: Due to the position of vehicles towing hooks, towbar hitch box is not welded square to cross tube.

1. Ensure all hardware items have been included.
2. Lift towbar up into position (driver's side first) and fit M12x30 bolts, spring washers and loose plates through large slots in vehicle towing hooks. (Do not fully tighten yet.)
3. Fit tapped plates on wire up into chassis rails and align with hole in bottom face of chassis.
4. Fit M12x30 bolts and spring washers through most forward mounting plates and align with tapped plates on wire.
5. Fit M10x30 bolts, spring washers and nuts for most rearward mounting plates.
6. Tighten all bolts to torque listing below.
7. Towbar rating sticker to be conspicuously located on inside rear end of the driver's door. (see diagram below)


NOTE: Hayman Reese recommends that you check your towball to ensure it complies to Australian Design Rules.

RECOMMENDED ASSEMBLY TORQUE LISTING

Diameter	Grade 4.6 Bolt	Grade 8.8 Bolt
	Nm	Nm
M6	3.5	9.5
M8	8.6	21.7
M10	16.9	43.4
M12	29.8	77.3
M16	74.0	189.8

FOR TOWING PURPOSES ONLY

For towing capacity details please refer to vehicle owner's manual or to the manufacturer. Overloading can void your warranties.



PLEASE NOTE: You must remove the Trailer Ballmount unless you are actually towing if it obscures your number plate. Failure to do so may result in a fine.

RL1692 - TO SUIT SUZUKI JIMNY 99-ON

