




Tow bar Fitting Instructions
 To Suit NISSAN PATHFINDER 7/05 onwards
 Part Number DS80
 Rating 1500Kg

WARNING:

1. Do not, drill, cut, weld or otherwise modify the tow bar.
2. If you are using electric welding on a motor vehicle, **always** check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could **destroy** any onboard computers. If in doubt, check with the vehicle's manufacturer.

1. Ensure all hardware items have been included.
2. Remove spare wheel.
3. Cut the bottom most face of the bumper as shown in the diagram (viewed from the underside of the vehicle).



Cut is 85mm wide, (shown by the hatched marking). It is centered between the mounting points visible on either side of the cut.

4. Lift Tow bar into position, matching holes in cross beam to holes in tow bar and support with a jack or similar.
5. Fit M12 x 80mm bolts through aligned holes in the tow bar and cross beam from the bottom up, while tapped plates on wires are positioned above the cross beam. Tighten these 6 bolts hand tight before lowering jack.
6. Fasten all bolts & nuts to torque listing below.
7. Trim excess wire off tapped plates if necessary.

NOTE: It is recommended that you check your tow ball to ensure it complies with Australian Design Rules.

RECOMMENDED ASSEMBLY TORQUE LISTING

Grade 8.8 Bolt

Diameter	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8

FOR TOWING PURPOSES ONLY

For towing capacity details please refer to vehicle owner's manual or to the manufacturer.

Tow bar Fitting Instructions
To Suit NISSAN PATHFINDER 7/05 onwards
Part Number DS80
Rating 1500Kg

PLEASE NOTE: You must remove the lug unless you are actually towing if it obscures your number plate. Failure to do so may result in a fine.

