



Towbar Fitting Instructions
To Suit HYUNDAI GETZ 3 & 5 DOOR HATCH 10-03-ON
Part Number HY20
Rating 700Kg

WARNING:

1. Do not, drill, cut, weld or otherwise modify the tow bar.
2. If you are using electric welding on a motor vehicle, **always** check that the vehicle is not equipped with electronic engine or instrument management equipment. Failure to do so could **destroy** any onboard computers. If in doubt, check with the vehicle's manufacturer.

- 1 Ensure all hardware items have been included
- 2 Remove bumper bar via
 - a) 4 screws under rear hatch lid
 - b) 4 screws at each wheel arch
 - c) 1 plastic trim button in the middle of lower lip of bumper
 - d) 2 bolts at end of each sub frame under bumper.
- 3 Cut bumper as per fig 1.
- 4 Fit tow bar to align with captive nuts on the sub frame (**outer edge on the driver side & inner edge on the passenger side**).
- 5 Tighten all bolts to torque listing below.
- 6 Refit bumper in the reverse of steps 2d to 2a.

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
	Nm
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M14	121.0
M16	189.8


FOR TOWING PURPOSES ONLY

For towing capacity details please refer to vehicle owner's manual or to the manufacturer. Overloading can void your warranties.

TRAILBOSS

Towbar Fitting Instructions
To Suit HYUNDAI GETZ 3 & 5 DOOR HATCH 10-03-ON
Part Number HY20
Rating 700Kg

Fig 1 Bumper Cut



Measure from centre of screw on underside of bumper

Area of bumper bar to be removed

Establish centre line of bumper bar Then mark as shown

