

MITSUBISHI OUTLANDER ZJ WAGON 11/12 – ON

PART NO.

UNT314

1. Remove floor panel from the luggage area.
2. Remove the rear centre trim.
3. Remove L/H side bottom trim. You may only have to part remove to gain access to the 10 way connector. Located half way in from the back just below the top trim.
4. Attach the 10 way connector from the trailer wire harness to the vehicles corresponding 10 way connector.
5. Mount the ECU to a secure location.
6. Screw the Earth wire to a grounding point on the vehicle.
7. Locate the rear most grommet in the spare wheel well and pierce a hole in the middle to allow the towbar wiring harness to be fed through the grommet and out under the vehicle. Ensure that any cable will be hidden when you replace the trims.
8. On the underside of the vehicle, pull the wiring harness through the grommet to meet the required length.
9. Fit the required socket to the wiring harness and mount the plug to the desired position.
10. Using cable ties secure the wiring harness to meet the required length.
11. In the engine bay beside the battery you will find a factory harness with a 4 way connector taped to it. Pull this connector free.
12. Connect the fuse holder to the matching 4 way connector.
13. Mount the ring terminal on the other end of the fuse holder to the positive side of the battery.
14. Insert fuse supplied.
15. Test towbar wiring with a trailer testing box.
16. Refit side trim.
17. Refit centre trim.
18. Replace the floor panel in the luggage area.

